




DE Gebrauchsanweisung

UP-Steckdose mit USB-Port

Bestimmungsgemäßer Gebrauch

Das Gerät entspricht dem Stand von Wissenschaft und Technik, sowie den geltenden Sicherheitsbestimmungen zum Zeitpunkt des Inverkehrbringens im Rahmen seiner bestimmungsgemäßen Verwendung.

Das Gerät ist bestimmt zum Aufladen von Mobiltelefonen oder anderen Geräten mit Micro-USB-Anschluss.

Das Gerät ist nicht für den gewerblichen Gebrauch bestimmt.

Jede andere Verwendung ist bestimmungswidrig. Durch bestimmungswidrige Verwendung, Veränderungen am Gerät oder durch den Gebrauch von Teilen, die nicht vom Hersteller geprüft und freigegeben sind, können unvorhersehbare Schäden entstehen! Jede nicht bestimmungsgemäße Verwendung bzw. alle nicht in dieser Gebrauchsanweisung beschriebenen Tätigkeiten am Gerät sind unerlaubter Fehlgebrauch außerhalb der gesetzlichen Haftungsgrenzen des Herstellers.

Zu Ihrer Sicherheit

Allgemeine Sicherheitshinweise

- Für einen sicheren Umgang mit diesem Gerät muss der Benutzer des Gerätes diese Gebrauchsanweisung vor der ersten Benutzung gelesen und verstanden haben.
- Beachten Sie alle Sicherheitshinweise! Wenn Sie die Sicherheitshinweise missachten, gefährden Sie sich und andere.
- Bewahren Sie alle Gebrauchsanweisungen und Sicherheitshinweise für die Zukunft auf.
- Wenn Sie das Gerät verkaufen oder weitergeben, händigen Sie unbedingt auch diese Gebrauchsanweisung aus.
- Das Gerät darf nur benutzt werden, wenn es einwandfrei in Ordnung ist. Ist das Gerät oder ein Teil davon defekt, muss es außer Betrieb genommen und fachgerecht entsorgt werden.
- Verwenden Sie das Gerät nicht in explosionsgefährdeten Räumen oder in der Nähe von brennbaren Flüssigkeiten oder Gasen!
- Ausgeschaltetes Gerät immer gegen unbeabsichtigtes Einschalten sichern.
- Benutzen Sie keine Geräte, bei denen der Ein-Aus-Schalter nicht ordnungsgemäß funktioniert.
- Halten Sie Kinder vom Gerät fern! Bewahren Sie das Gerät sicher vor Kindern und unbefugten Personen auf.
- Überlasten Sie das Gerät nicht. Benutzen Sie das Gerät nur für Zwecke, für die es vorgesehen ist.

- Immer mit Umsicht und nur in guter Verfassung arbeiten: Müdigkeit, Krankheit, Alkoholeinfluss, Medikamenten- und Drogeneinfluss sind unverantwortlich, da Sie das Gerät nicht mehr sicher benutzen können.
- Dieses Gerät ist nicht dafür bestimmt, durch Personen (einschließlich Kinder) mit eingeschränkten physischen, sensorischen oder geistigen Fähigkeiten oder Mangel an Erfahrung und/oder Wissen benutzt zu werden, es sei denn, sie werden durch eine für ihre Sicherheit zuständige Person beaufsichtigt oder erhielten von dieser Anweisungen, wie das Gerät zu benutzen ist.
- Stellen Sie sicher, dass Kinder nicht mit dem Gerät spielen.
- Immer die gültigen nationalen und internationalen Sicherheits-, Gesundheits- und Arbeitsvorschriften beachten.

Elektrische Sicherheit

Installation nur durch Personen mit einschlägigen elektrotechnischen Kenntnissen und Erfahrungen. *) Durch eine unsachgemäße Installation gefährden Sie:

- Ihr eigenes Leben
 - Das Leben der Nutzer der elektrischen Anlagen
- Mit einer unsachgemäßen Installation riskieren Sie schwere Sachschäden z.B.: durch Brand. Es droht für Sie die persönliche Haftung bei Personen- und Sachschäden.

Wenden Sie sich an einen Elektroinstallateur!

*) Erforderliche Fachkenntnisse für die Installation

Für die Installation sind insbesondere folgende Fachkenntnisse erforderlich:

- die anzuwendenden "5 Sicherheitsregeln": Freischalten; gegen Wiedereinschalten sichern; Spannungsfreiheit feststellen; Erden und Kurzschließen; benachbarte und unter Spannung stehende Teile abdecken oder abschränken;
- Auswahl des geeigneten Werkzeugs, der Messgeräte und ggf. der persönlichen Schutzausrüstung;
- Auswertung der Messergebnisse;
- Auswahl des Elektroinstallationsmaterials zur Sicherstellung der Abschaltbedingungen;
- IP-Schutzarten;
- Einbau des Elektroinstallationsmaterials;
- Art des Versorgungsnetzes (TN-System, IT-System, TT-System) und die daraus folgenden Anschlussbedingungen (klassische Nullung, Schutzerdung, erforderliche Zusatzmaßnahmen etc.).

Bei Arbeiten an der Steckdose muss sichergestellt sein, das die entsprechende Sicherung/der entsprechende Sicherungsautomat ausgeschaltet ist, d.h. die Steckdose muss spannungsfrei sein.

Gerätespezifische Sicherheitshinweise

- Gerät nur in Innenräumen betreiben.
- Das Gerät niemals Wasser oder anderen Flüssigkeiten aussetzen.
- Das Gerät darf nicht in Räumen mit Badewanne, Dusche oder Schwimmbecken sowie in der Nähe von Waschbecken oder Wasseranschlüssen betrieben werden.
- Symbole, die sich an Ihrem Gerät befinden, dürfen nicht entfernt oder abgedeckt werden. Nicht mehr lesbare Hinweise am Gerät müssen umgehend ersetzt werden.



Vor Inbetriebnahme Gebrauchsanweisung lesen und beachten.



Das Gerät darf nur in trockenen Innenräumen benutzt werden.



Hinweis: Das tatsächliche Aussehen Ihres Gerätes kann von den Abbildungen abweichen.

► Abb. 1

Installationshinweise:

- Spannung über Sicherung abschalten, Spannungsfreiheit prüfen.
- Aderenden ca. 14 mm abisolieren.
- Einzeladern gemäß Anschlussschaltbild fachgerecht anschließen.
- Korrektheit der Anschlüsse prüfen. Bei Bedarf können die Adern wieder gelöst werden (Adern durch Drücken des Löseknopfes und gleichzeitiger Drehbewegung der Ader lösen).
- Steckdose in der Anschlussdose ausrichten und mit den Spreizkrallen (Achtung! Es darf keine Ader/Isolierung/Leitung durch die Krallen beschädigt werden) oder Dosenschrauben befestigen.
- Steckdosenrahmen auf den Sockel drücken, bis dieser vollständig einrastet.
- Erst nach einwandfreier Installation Spannung über Sicherung zuschalten.

Montagedarstellung:

► Abb. 2

Siehe Abbildung (Abbildung ähnlich).

Demontage:

- Spannung über Sicherung abschalten, Spannungsfreiheit prüfen
- Steckdosenrahmen abziehen.
- Schraubkrallen oder Dosenschrauben lösen und Steckdose aus Anschlussdose entnehmen.
- Adern durch drücken des Löseknopfes und gleichzeitiger Drehbewegung der Ader lösen.
- Vor Wiedereinschalten der Spannung Adern durch entsprechende Klemmen in Anschlussdose sichern.

Bedienung



GEFAHR! Lebensgefahr durch elektrischen Schlag! Die zulässige Maximalleistung angeschlossener Verbraucher darf nicht überschritten werden (► Technische Daten).



GEFAHR! Lebensgefahr durch elektrischen Schlag! Spannungsfreiheit ist nur bei gezogenem Netzstecker gewährleistet.



Hinweis: Der USB-Anschluss dient nur als Stromquelle. Er kann nicht zur Datenübertragung benutzt werden.

– Verbraucher anschließen

Reinigung und Pflege

- Vor der Reinigung Spannung über Sicherung abschalten und Spannungsfreiheit prüfen
 - Achten Sie darauf, dass keine Flüssigkeit in das Gehäuse gelangt
 - Verwenden Sie keine ätzenden und scheuernden Reinigungsmittel
 - Verwenden Sie zur Reinigung ein trockenes, fusselfreies Tuch
- Spannung über Sicherung abschalten, Spannungsfreiheit prüfen
 - Rahmen mit einem leicht angefeuchteten Tuch abwischen (keine scharfen Reinigungsmittel benutzen). Darauf achten, dass keine Flüssigkeit/Feuchtigkeit in das Gehäuse gelangt.

Aufbewahrung, Transport

Aufbewahrung

- Lagern Sie das Gerät und alle Zubehöreile an einem trockenen, gut belüfteten Ort.
- Schützen Sie das Gerät und sein Zubehör bei längeren Stillstandszeiten vor Verschmutzung und Korrosion.

Transport

- Beim Versand nach Möglichkeit die Originalverpackung verwenden.

Störungen und Hilfe

Wenn etwas nicht funktioniert...



GEFAHR! Gefahr für Leib und Leben! Unsachgemäße Reparaturen können dazu führen, dass Ihr Gerät nicht mehr sicher funktioniert. Sie gefährden damit sich und Ihre Umgebung.



GEFAHR! Lebensgefahr durch elektrischen Schlag! Alle Arbeiten zur Beseitigung möglicher Störungen sollten im ausgeschalteten Zustand (Sicherung aus) durchgeführt werden. Alle Arbeiten sollten von einem qualifizierten Elektriker ausgeführt werden.

Offt sind es nur kleine Fehler, die zu einer Störung führen. Meistens können Sie diese leicht selbst beheben. Bitte sehen Sie zuerst in der folgenden Tabelle nach, bevor Sie sich an den Händler wenden. So ersparen Sie sich viel Mühe und eventuell auch Kosten.

Fehler/Störung	Ursache	Abhilfe
Die Steckdose/der Schalter funktioniert nicht.	Keine Netzspannung?	Sicherung prüfen. Fachkraft kontaktieren.
	Angeschlossenes Gerät defekt?	Angeschlossenes Gerät prüfen, ggf. austauschen, wenn möglich.
	Steckdose/Schalter über Schalter ausgeschaltet?	Schalterstellung prüfen
	Anschlusskabel defekt?	Fachkraft kontaktieren.
	Anschluss inkorrekt?	Sicherung ausschalten und Anschluss anhand der Anschlusszeichnung prüfen. Fachkraft kontaktieren.

Können Sie den Fehler nicht selbst beheben, wenden Sie sich bitte direkt an den Händler. Beachten Sie bitte, dass durch unsachgemäße Reparaturen auch der Gewährleistungsanspruch erlischt und Ihnen ggf. Zusatzkosten entstehen.

Entsorgung

Gerät entsorgen

Das Symbol der durchgestrichenen Mülltonne bedeutet: Batterien und Akkus, Elektro- und Elektronikgeräte dürfen nicht in den Hausmüll. Sie können umwelt- und gesundheitsschädigende Stoffe enthalten.

Verbraucher sind verpflichtet, Elektro-Altgeräte, Gerätealtbatterien und Akkus getrennt vom Hausmüll über eine offizielle Sammelstelle zu entsorgen um eine sachgerechte Weiterverarbeitung zu gewährleisten. Die Rückgabe kann gemäß gesetzlicher Regelung kostenfrei z. B. über einen kommunalen Entsorgungsbetrieb oder über einen Händler erfolgen.

Batterien, Akkus und Lampen, die nicht fest in Elektro-Altgeräten verbaut sind und zerstörungsfrei entnommen werden können, müssen vor der Entsorgung entnommen und getrennt entsorgt werden. Lithiumbatterien und Akkupacks aller Systeme sind nur im entladenen Zustand bei den Rücknahmestellen abzugeben. Die Batterien sind immer durch abkleben der Pole vor Kurzschlüssen zu sichern.

Jeder Endnutzer ist selbst für die Löschung personenbezogener Daten auf den zu entsorgenden Altgeräten verantwortlich.

Verpackung entsorgen

Die Verpackung besteht aus PET-Kunststoffkarton und entsprechend gekennzeichneten Kunststoffteilen, die recycelt werden können.

- Führen Sie diese Materialien der Wiederverwertung zu.

Technische Daten

Artikelnummer	311913
Betriebsspannung	230 V~, 50 Hz
Ausgang (USB)	5.0V=, max.2.4A(12.0W)

Max. Leistung angeschlossener Verbraucher 3500 W

Informationsanforderungen USB Typ A

Veröffentlichte Angaben	Wert und Genauigkeit	Einheit
Name oder Handelsmarke des Herstellers, Handelsregisternummer und Anschrift	OBI Group Sourcing GmbH Albert-Einstein-Str. 7–9 42929 Wermelskirchen GERMANY	
Modellkennung	311913	
Eingangsspannung	230	V
Eingangswechselstromfrequenz	50	Hz
Ausgangsspannung	5,0	V
Ausgangsstrom	2,4	A
Ausgangsleistung	12,0	W
Durchschnittliche Effizienz im Betrieb	81.73	%
Effizienz bei geringer Last (10%)	76.28	%
Leistungsaufnahme bei Nulllast	0.04	W

GB Operating instructions

UP socket with USB port

Intended use

When used for its intended purpose, this device corresponds to the state of the art, as well as to the current safety requirements at the time of its introduction.

The device is intended for the charging of mobile telephones or for other electrical devices with a micro-USB port.

The device is not suitable for commercial or industrial use.

Any other type of use is inappropriate. Improper use or modifications to the device or the use of components that are not tested and approved by the manufacturer may result in unforeseen damage!

Any use that deviates from its intended use and is not included in these instructions is considered unauthorised use and relieves the manufacturer from his or her legal liability.

For your safety

General safety instructions

- To operate this device safely, the user must have read and understood these instructions for use before using the device for the first time.
- Observe all safety instructions! Failure to do so may cause harm to you and others.
- Retain all instructions for use, and safety instructions for future reference.
- If you sell or pass the device on, you must also hand over these operating instructions.
- The device must only be used when it functions properly. If the product or part of the product is defective, it must be taken out of operation and disposed of correctly.
- Never use the device in a room where there is a danger of explosion or in the vicinity of flammable liquids or gases.
- Always ensure that a device which has been switched off cannot be restarted unintentionally.
- Do not use devices with an on/off switch that does not function correctly.
- Keep children away from the device! Keep the device out of the way of children and other unauthorised persons.
- Do not overload the device. Do not use the device for purposes for which it is not intended.
- Exercise caution and only work when in good condition: If you are tired, ill, if you have ingested alcohol, medication or illegal drugs, do not use the device, as you are not in a condition to use it safely.
- This product is not intended to be used by persons (including children) or who are limited in their physical, sensory or mental capacities or who lack experience and/or knowledge of the product unless they are supervised, or have been instructed on how to use the product, by a person responsible for their safety.
- Ensure that children are not able to play with the device.
- Always comply with all applicable domestic and international safety, health, and working regulations.

Electrical safety

Installation may only be carried out by persons with the appropriate electrical knowledge and experience.

With an unprofessional installation **you** will risk:

- your own life
- the lives of users of the electrical systems.

With an unprofessional installation, **you** risk serious damage to property, for example: as a result of fire.

You may also be held personally liable in the event of injuries or property damage.

Consult a professional electrical installer!

* Required technical knowledge for the installation process

For installation purposes, the following specific technical knowledge is required:

- the applicable "5 safety rules": Deactivate; Secure to prevent being switched back on; Ensure no power is flowing; Earth and short-circuit; Cover or screen off neighbouring, power carrying items;
- Selection of suitable tools, the measuring devices and, if required, personal protective equipment;
- Evaluation of the measuring results;
- Selection of the electrical installation materials to secure working conditions;
- IP protection types;
- Incorporation of electrical installation material;
- Type of power supply network (TN system, IT system, TT system) and the resulting connection conditions (traditional protective multiple earthing, protective earth, required additional measures etc.)

When working on the socket, you must ensure that the appropriate fuse/circuit breaker is deactivated; in other words, the socket must be without power.

Device-specific safety instructions

- Operate device only indoors.
- Never expose device to water or other fluids.
- The device may not be operated in rooms with bathtubs, shower or swimming pools as well as not near sinks or water connections.
- Symbols appearing on your product may not be removed or covered. Information on the product that are no longer legible must be replaced immediately.



Read and observe the operating instructions before using the product for the first time.



The device may only be used in dry, indoor rooms.

An overview of your unit



Note: The actual appearance of your device may differ from the illustrations.

► Figure 1

Installation notes:

1. Deactivate the voltage using the fuse, check to ensure that there is no power flowing.
2. Strip the ends of the cores by approximately 14 mm.
3. Connect the individual cores correctly in accordance with the connection circuit diagram.
4. Check to ensure that the connections are correctly carried out. If necessary, the cores can be undone again (release the cores by clicking the release button and simultaneously rotating the core).
5. Align the socket in the terminal and fasten it with the spread clamps (**Caution! no cores/insulation/line may be damaged by the claws**) or with Allen bolts.
6. Push the socket frame onto the base until it engages fully.
7. Only activate the voltage via the fuse when installation has been completed with no problems.

Installation representation:

► Figure 2

see diagram (similar diagram).

Removal:

1. Deactivate the voltage using the fuse, check to ensure that there is no power flowing.
2. Pull off the socket frame.

3. Remove the screw claws or socket screws and take the socket out of the connection socket.
4. Release the cores by pressing the release button and simultaneously rotating the cores.
5. Before switching the power back on, secure the cores in the connection socket using appropriate terminals.

Operation



DANGER! Risk of death through electric shock! The permitted maximum power for the connected consumers must not be exceeded (► Technical data).



DANGER! Risk of death through electric shock! No voltage can only be ensured when the mains plug is unplugged.



Note: The USB-Connection is only used as source of power. This USB-Connection cannot be used for the data transmission.

- Connect consumer appliance

Cleaning and maintenance

- Switch off voltage via fuse before cleaning and check to ensure that there is no power flowing
 - Make sure that no fluid seeps into the housing.
 - Do not use caustic and abrasive cleaning agents
 - Use a dry, lint-free cloth for cleaning
1. Deactivate the voltage using the fuse, check to ensure that there is no power flowing.
 2. Wipe the frame with a damp cloth (do not use aggressive cleaning agents). Ensure that no liquid/dampness is introduced into the housing.

Storage and transport

Storing

- Store the device and any accessories in a dry, well-ventilated place.
- In case of longer periods without operation, protect the device and its accessories against soiling and corrosion.

Transport

- Use the original packaging to ship whenever possible.

Troubleshooting

If something stops working...



DANGER! Danger to life and limb! Improper repairs can result in the product functioning unsafely. This endangers yourself and your environment.



DANGER! Risk of fatal injury due to electric shock! All work to eliminate possible faults should be carried out with the fuse switched off. All work should be carried out by a qualified electrician.

Malfunctions are often caused by minor faults. You can easily remedy most of these yourself. Please consult the following table before contacting the vendor. You will save yourself a lot of trouble and possibly money too.

Fault/malfuntion	Cause	Remedy
The socket/switch button does not work	No mains voltage?	Check fuse. Contact a specialist.
	Connected device defective?	Check connected device, replace if necessary if possible.
	Socket/switch button switched off via switch?	Check switch position

Fault/malfuntion	Cause	Remedy
	Connection cable defective?	Contact a specialist.
	Incorrect connection?	Switch off the fuse and check the connection according to the wiring diagram. Contact a specialist.

If you can't fix the fault yourself, contact your nearest vendor. Please be aware that any improper repairs will also invalidate the warranty and additional costs may be incurred.

Disposal

Disposal of the appliance

A crossed-out wheellie bin icon means: Batteries and rechargeable batteries, electrical or electronic devices must not be disposed of with household waste. They may contain substances that are harmful to the environment and human health.



Consumers must dispose of waste electrical devices, spent portable batteries and rechargeable batteries separately from household waste at an official collection point to ensure that these items are processed correctly. The product can be returned free of charge in accordance with the legal requirements, for example through a municipal waste disposal company or a dealer.

Batteries, rechargeable batteries and lamps that are not permanently installed in waste electrical equipment and can be removed in a non-destructive way must be removed and disposed of separately before disposal of the equipment. Lithium batteries and rechargeable battery packs of all systems are only to be handed in to the waste collection points in a discharged state. The batteries must always be protected against short circuits by taping off the poles.



All end users are responsible for deleting any personal data stored on waste devices prior to their disposal.

Disposing of the packaging

The packaging consists of PET plastic card and marked plastics that can be recycled.

- Take these materials to a recycling centre.



Technical data

Item number	311913
Operating voltage	230 V~, 50 Hz
Output (USB)	5.0V~ Max. 2.4A(12.0W)
Max. power of connected consumer appliance	3500 W

Information requirements

USB type A

Information published	Value and precision	Unit
Manufacturer's name or trade mark, commercial registration number and address	OBI Group Sourcing GmbH Albert-Einstein-Str. 7–9 42929 Wermelskirchen GERMANY	
Model identifier	311913	
Input voltage	230	V
Input AC frequency	50	Hz
Output voltage	5.0	V
Output current	2.4	A
Output power	12.0	W
Average active efficiency	81.73	%
Efficiency at low load (10%)	76.28	%